



1. Turn underlay 100mm up abutments.
2. Fix short slates as top course to maintain gauge.
3. Fix code 6 lead tack, 50mm wide at 300 - 500mm centres and laps.
4. Fix code 4 lead apron flashing in 1.5 to 2.0m lengths wedge at the laps and at 450mm centres and secure into the brickwork joints to a depth at least 25mm, dressed down 150mm over the slates.