



TYPICAL CHANGE OF ROOF
PITCH DETAIL

1. Complete slating lower slope as for standard roof upper edge.
2. Fix layer boards to rafters at the intersection of the two roofs, equal in thickness to the battens.
3. Fix a tilting fillet to the top edge of the upper layer board, equal in thickness to the battens.
4. Fix code 5 lead apron flashing over the tilting fillet and dress down over the heads of the slate below by at least mm. Fix copper straps at 300 - 500mm centres.
5. Slate and batten upper slope as standard eaves with the bottom course projecting below the tilting fillet by 50 to 60mm.