



1. Lay 600mm wide strip of underlay over the valley, underlapping the main underlay.
2. Cut slate-and-a-half carefully ensuring that adequate width is maintained at the tail.
3. Fix slates to interleave with code 3 lead, or stainless steel, soakers nailed to battens at the top edge to provide a straight, watertight and close mitred joint. The size of the soaker must not be less than one slate's length and in its width at least a slate on both sides at the head and at least half a slate on both sides at the tail.